Auto-steering.
Installed on your farm.

For the tractor you already own.



Actual Fieldway demonstration footage. Installation shown is one example.

2.5 cm RMS*

WITH FIXED RTK

RTK correction service is not included.

Keep your existing tractor

Retrofit a compatible tractor with electric steering.

Reduce overlap

Follow planned straight and curved guidance lines.

Automatic U-turns

Configure headland turning for your field work.

$9,800 + HST, installed

Standard installation, calibration and first training.

*Manufacturer-rated in dry fields at up to 10 km/h, with fixed RTK and correct installation/calibration. Tractor compatibility must be checked. Operator supervision is required.

Three core components.

Know what each unit does - and where it goes.

01



DP10 DISPLAY

10.1-inch touchscreen

View guidance. Set up tasks.

In the cab, within easy reach.

02



FM5

Electric steering wheel

Turns the steering shaft.

At the tractor steering wheel.

03




FC3 PRO

GNSS receiver / controller

Positioning and vehicle control.

On the roof, on the centreline.

Where it goes.



03 Roof centreline
FC3 Pro combines GNSS reception and control.

01 Driver's workspace
DP10 sits where the operator can see and reach it.


02 Steering shaft
FM5 fits using tractor-specific mounting hardware.

Installation overview only. Final brackets, mounting positions and cable routing depend on the tractor.


Mounting hardware, wiring and small parts: confirm the full kit for your tractor in the quote.

Guidance for the work you do.

Plan a pass. Set up the turn. Stay in control.



AB line setup



Automatic headland-turn settings

Actual software examples from the manufacturer's user manual; shown values are illustrative.

Straight & curved guidance

Plan successive passes using AB lines or curves.

Automatic headland turns

Included: set radius, direction and trigger settings.

Slope compensation

Compensates for vehicle tilt during field guidance.

Resume an interrupted task

Continue field work without starting a task from scratch.

Built around your field work.

SEEDING / SPRAYING / TILLAGE / FERTILIZING

Task sharing is supported. Available functions depend on installed configuration and setup. The operator remains responsible for the tractor and implement.

Start with your tractor.

$9,800 + HST, installed

01 Your tractor

Bring the make, model, year and a photo of the steering area.

02 Your field work

Tell us the main tasks, implement widths and field conditions.

03 Your correction setup

Let us know if you already use an RTK service or base station.

Confirm the complete setup before you buy.

- / Hardware and tractor-specific mounting
- / Installed by Fieldway - calibration and training included
- / Correction signal, connectivity and any recurring fees

2-year warranty on main components

Cables and accessories: 1 year. Written service terms apply.

Ask us about a demo.

Check compatibility. See the system. Discuss your field work.

fieldway.ca

pilot.fieldway.ca/equipment

SCAN TO ENQUIRE

Standard installation within 100 km; travel and non-standard adapters quoted separately. RTK correction service and data SIM are not included. Operator supervision is required.